

# B&P

LAMP SUPPLY, INC.

843 Old Morrison Hwy., McMinnville, TN 37110

931-473-3016

fax: 931-473-3014

CustomerService@bplampsupply.com

## Wall Bracket Lamp Instructions

Tools Required: Flat Head Screw Driver, Stud Finder, Drill, 3/32 Drill Bit, Level

Contents: Bowl, Arm, Wall Bracket, (1) short screw, (2) long wall screws.



Installation:

- 1) Locate the stud in the wall.
- 2) Place wall bracket on stud and mark the wholes.
- 3) Using the level, make sure the wholes are plum.
- 4) Predrill marked wholes and attach the bracket to the wall with the long screws and screw driver.
- 5) Mount the bowl to the arm with the short flat head screw.
- 6) Slide the shaft of the arm into the wall bracket.

The Wall Bracket Lamp is now ready for the font and other parts of the lamp.

